


Installation Guidelines & Methods

Longitudinal Wrapping

For pipes with a circumference of less than 6" (150 mm) in relation to the width of the Denso Stoneguard™:


1. Unroll the mesh longitudinal to the pipe which is to be protected.
2. Place the mesh below the pipe.
3. Wrap the mesh around the pipe, overlapping the edges by a minimum of 6" (150 mm).
4. The mesh shall be secured by plastic straps, heat bonding or similar method as agreed.
5. The backfill process can begin after all mesh pieces are secured to the pipe.



Circumferential Wrapping

For pipes with a circumference larger than the roll width:


1. Cut the mesh into pieces a minimum of 6" (150 mm) longer than the circumference of the pipe.
2. Wrap the pipe with the pre-cut mesh, overlapping the adjacent installed mesh by a minimum of 100 mm.
3. The mesh shall be secured by plastic straps, heat bonding or similar method as agreed.
4. The backfill process can begin after all mesh pieces are secured to the pipe.



Spiral Wrapping


This process can be applied to larger circumference pipes:

1. Start wrapping the pipe moving along the length of the pipe, so that the mesh overlaps by a minimum of 100 mm.
2. The mesh shall be secured by plastic straps, heat bonding or similar method as agreed.
3. The backfill process can begin after all mesh pieces are secured to the pipe.



Application Diagram

Section View



Pub. No. 669.09.2023



WINN & COALES (DENSO) LTD

TEL: +44 (0) 208 670 7511
FAX: +44 (0) 208 761 2456
EMAIL: mail@denso.net
WEB: www.denso.net

Winn & Coales (Denso) Ltd
33 - 35 Chapel Road
London SE27 0TR
UNITED KINGDOM

